



Forbrugstabel

Placering uden for flisekryds

A cm	10	15	20	25	30	40	45	50	55	60	75	80	90	100	120	150	180	200		
10	1980																			
15	1317	876																		
20	495	328	490																	
25	396	263	391	312																
30	660	438	488	389	431															
40	495	328	365	291	322	240														
45	440	292	324	258	285	213	189													
50	396	263	291	232	256	191	169	152												
55	360	239	264	211	232	173	154	138	125											
60	330	219	242	193	212	158	141	126	114	105										
75	396	263	258	206	212	158	140	126	114	104	99									
80	371	246	241	192	198	148	131	117	107	97	93	87								
90	330	219	214	171	176	131	116	104	94	86	82	77	68							
100	297	197	192	153	157	117	104	93	84	77	73	68	61	54						
120	330	219	200	160	157	117	104	93	84	77	71	66	59	52	49					
150	330	219	192	153	146	109	96	86	78	71	64	60	53	47	44	38				
180	330	219	186	149	139	103	91	82	74	68	60	56	49	44	40	34	31			
200	347	230	192	153	140	104	92	83	75	68	59	55	49	44	39	33	30	28		
	10	15	20	25	30	40	45	50	55	60	75	80	90	100	120	150	180	200	B cm	




Eksempel



60 x 120 cm = 77 stk. til 10 m²

Placering på 30 x 60 cm flise



Forbrug pr. 10 m² = 212 stk.